

INSTRUCTION MANUAL



TR24-230-100N

24VAC Magnetic Transformer

Thank you very much for your purchase of TOKISTAR products.

To ensure safe use of this product, be sure to read this instruction manual before use. Please keep this manual for future reference.

SPECIFICATIONS (mm)



Specifications

Input : 230VAC 50/60Hz 0.65A

Output : 24VAC 100VA

Power Factor : 0.97

Operating Temp. : 0~40°C (Indoor use only)

Surface Temp. : 38°C (Ambient 25°C)

Heat Loss : 13.8kcal/h

Mechanical Specifications

Case Material : Al, SPC

Dimensions : W 155 x L 153 x H 100 mm

Weight : Approx. 3.5kg

IP Rating : IP20



Please read before use

- Please make sure that the type and quantity of the product matches the information in the shipping instructions.
- The product is carefully packed at the time of shipment, but please inform us immediately if the product is damaged when you open the package.



PRECAUTIONS

1. Read all instructions completely before beginning installation.
2. Turn off electricity before beginning installation. Otherwise, LEDs may be damaged.
3. All wiring is to be performed by a qualified electrician.
4. Installation must comply with the safety standards of each country and all applicable codes.
5. Turn main supply to LED Driver ON only after all connections have been made and tested.
6. The Magnetic Transformer is for dry location only. It must be installed within an enclosure suitable for the environment.